

Preparation, Installation and Maintenance Instructions for Tubshowers and Showers

Before Starting:


- Remove the unit from the carton. Do not destroy the cardboard until you have inspected the unit carefully. Should your inspection reveal any damage or defect in the finish, do not install the unit – contact your distributor immediately. The warranty does not cover damages or defects to the finish claimed after the bath has been installed. Longevity's responsibility for shipping damages ceases upon delivery of the product in good order to the carrier. Refer any claims for damages to the carrier.
- It is always recommended to have a professional and competent plumber do the plumbing installations.
- Please note if for any reason you must drill a hole in an acrylic fixture, always start drilling on acrylic surface and drill through (hole saw recommended).
- To protect the unit during installation, we recommend that you put a piece of cardboard on the bottom of the tub.
- If the unit is covered with a polyethylene film, remove the protective film at the last moment to grant maximum protection during installation procedures. However, remove film where surfaces will be in permanent contact with another surface.
- Build a solid frame inside 1/2" to 3/4" using dimensions listed in the technical data. Please note that all three piece units will require notching in the frame to accommodate joints.
- Check that floor is level, adjust as necessary.
- The drain location on the tub/shower is shown but actual installation will depend on waste/overflow which is purchased separately.
- Place unit into framework, shim as necessary and plum vertical.
- Install plumbing fixtures according to individual manufacturer's instructions.
- Fasten the unit to the frame using drywall screws. Be careful not to over tighten or bury the screws as this may cause the acrylic to crack.

Technical Data – Showers & Tubshowers

Model#	A Wide	B Deep	C High	Door Opening	D Drain	E Drain	Floor Dimension
2170	70"	36"	88"	60"	17 1/2"	11 1/2"	50" x 20"
2173	70"	37 1/2"	88"	60"	17 1/2"	11 1/2"	50" x 20"
9170	70"	36"	88"	60"	19"	35"	60" x 28"
9173	70"	37"	88"	60"	19"	35"	60" x 28"
2060	60"	32"	84"	51 1/2"	16"	8"	45" x 23"
2063	59 1/2"	32"	84"	51 1/2"	16"	8"	45" x 23"
9160	60"	32"	84"	51 1/2"	16"	7 3/8"	
9163	59 1/2"	32"	84"	51 1/2"	16"	7 3/8"	
AL 9161	60"	32"	84"	51 1/2"	16"	7 3/8"	
AL 9161-3	59 1/2"	32"	84"	51 1/2"	16"	7 3/8"	
9252	51"	36 1/2"	83"	43"	17"	26 1/4"	
9253	51"	36 1/2"	83"	43"	17"	25"	
2048	48"	32"	84"	40"	15"	24"	
2043	48"	32"	84"	40"	15 1/2"	24"	
9241	41"	36"	84"	32"	16"	20 1/2"	
8836 N	36"	34"	84"	29 1/2"	16"	18"	
8836	36"	30"	84"	29 1/2"	15"	18"	
8845	48"	32"	84"	39"	15"	24"	
2040 RF	41 1/4"	46 1/2"	79"	36" RF	11 1/2"	11 1/2"	
2042 RF	41 1/4"	46 1/2"	79"	36" RF	11 1/2"	11 1/2"	
2040 NA	41 1/4"	43 1/2"	79"	38" NA	12 1/2"	12 1/2"	
2042 NA	41 1/4"	43 1/2"	79"	38" NA	12 1/2"	12 1/2"	

- Test the installation before finishing around with trim.
- Remove the protective tape from the unit and clean with a mild cleaner to remove construction dirt and residue.

Please Note: All Measurements are actual unit sizes.



NOTE: A frame similar to this will be required if you are building a new bathroom. If unit is being installed in an existing bathroom, simply insert your new 3 piece tubshower in the same location as the old bathtub.



LONGEVITY
ACRYLICS INC